

290921

R020225

SCAFCO®

TEMPERATURE CABLE BRACKET

INSTALLATION INSTRUCTIONS






TABLE OF CONTENTS

TABLE OF CONTENTS..... 1

BRACKET TO RAFTER INSTALLATION (SINGLE RAFTER) 2

BRACKET TO RAFTER INSTALLATION (OPI) (SINGLE RAFTER) 3

BRACKET TO RAFTER INSTALLATION (BACK-TO-BACK RAFTER) 4

BRACKET TO RAFTER INSTALLATION (OPI) (BACK-TO-BACK RAFTER) 5

CABLE TO ROOF RIB INSTALLATION..... 6


BRACKET TO ROOF RIB INSTALLATION 7

BRACKET TO ROOF RIB INSTALLATION (OPI) 8

CABLE HANGING ANGLE INSTALLATION 9

ROOF REINFORCING RIB INSTALLATION 10

BRACKET TO RAFTER INSTALLATION (SINGLE RAFTER)




CAUTION!

IF BIN IS EQUIPPED WITH
SWEEP AUGER, THE LOOP
ON THE BOTTOM OF THE
CABLE MUST CLEAR THE
HEIGHT OF THE AUGER.


IMPORTANT:

NUT ON EYEBOLT MUST BE
THREADED DOWN AS CLOSELY
AS POSSIBLE TO THE EYE.
EYE ON EYEBOLT MUST RUN
PARALLEL TO ROOF RAFTER
OR CABLE SUPPORT.

BRACKET TO RAFTER INSTALLATION (OPI) (SINGLE RAFTER)



BRACKET TO RAFTER INSTALLATION (BACK-TO-BACK RAFTER)




CAUTION!

IF BIN IS EQUIPPED WITH
SWEEP AUGER, THE LOOP
ON THE BOTTOM OF THE
CABLE MUST CLEAR THE
HEIGHT OF THE AUGER.


NOTES:

1. Make sure anchor plate lies flat on floor beneath cable.
2. Tie down with recommended string.
3. Repeat every time bin is empty.

BRACKET TO RAFTER INSTALLATION (OPI) (BACK-TO-BACK RAFTER)




CABLE TO ROOF RIB INSTALLATION



NOTE:

1. Make sure anchor plate lies flat on floor beneath cable.
2. Tie down with recommended string.
3. Repeat every time bin is empty.


BRACKET TO ROOF RIB INSTALLATION



NOTE:


1. Make sure anchor plate lies flat on floor beneath cable.
2. Tie down with recommended string.
3. Repeat every time bin is empty.

BRACKET TO ROOF RIB INSTALLATION (OPI)



CABLE HANGING ANGLE INSTALLATION

(27' – 42' DIA. SILO 64'+ EAVE HEIGHT)



CAUTION!


IF BIN IS EQUIPPED WITH SWEEP AUGER, THE LOOP ON THE BOTTOM OF THE CABLE MUST CLEAR THE HEIGHT OF THE AUGER.

IMPORTANT:

NUT ON EYEBOLT MUST BE THREADED DOWN AS CLOSELY AS POSSIBLE TO THE EYE. EYE ON EYEBOLT MUST RUN PARALLEL TO ROOF RAFTER OR CABLE SUPPORT.

ROOF REINFORCING RIB INSTALLATION

STANDARD ON 39' & 42' BINS ONLY
(OPTIONAL PURCHASE ON OTHER BIN DIAMETERS)





SCAFCO Grain Systems Company

6200 E. Main Avenue

PO Box 11215

Spokane, WA 99211-1215, USA